CRTSPIRIT
PIR Motion Sensor

Safety Instruction and Warning

WARNING:

READ CAREFULLY BEFORE INSTALLING.

Installation should only be conducted by a qualified electrician in accordance with NEC and any relevant local building codes.

Risk of fire or electric shock. Fixture installation requires knowledge of luminaires electrical systems. If not qualifies, do not attampt installation. Contact a qualified electrician.

Be certain electrical power is OFF before and during installation and maintenance.

Fixtures must be connected to a wiring system with an equipment-grounding conductor.

Make sure the supply voltage is the same as the rated luminaire Fixtures voltage.

Wear gloves and safety glasses at all times when removing luminaire from carton, installing, servicing or performing maintenance.

Installation Instruction

Step 1

Turn the sensor to see the label at the back then unscrew the green terminal which shows LED.

Diffusion Lighting
BY RJCROSS

diffusionlighting.com
1-(866)-RJCROSS (752-7677)

5 YEAR WARRANTY

CRTSPIRIT
PIR Motion Sensor

Step 2

Insert the LED Ribbon's wire into the terminal then tighten the screws.

Step 3

Unscrew the another green terminal on the sensor.

CRTSPIRIT
PIR Motion Sensor

Step 4

Insert the wires from the power supplier and tighten the screws.

Step 5

Finished.

Diffusion Lighting
BY RJCROSS

diffusionlighting.com
1-(866)-RJCROSS (752-7677)

5 YEAR WARRANTY